



Human Vibration



Copyright© 2002
Brüel & Kjær Sound and Vibration Measurement A/S
All Rights Reserved

Hand-arm Vibration




Long-term exposure can cause white-finger or dead-finger syndrome

Symptoms:

- Tingling
- Numbness
- Blanching
- Over-reaction to coldness


Whole-body Vibration



Long-term exposure can cause severe damage especially to the lumbar region of the spine


Short-term symptoms:

- Fatigue
- Headache
- Slower reactions
- Nausea
- Insomnia




Mechanical Models of the Human Body


Whole body



Hand-arm



Transmission of Vibration through the Body



Standards for Human Vibration

INTERNATIONAL STANDARD



2631

ISO 2631-1:1997
“Mechanical vibration and
shock – Evaluation of human
exposure to **whole-body**
vibration,
Part 1, General Requirements”.


INTERNATIONAL STANDARD



5349

ISO 5349-1986
“Mechanical vibration -
Guidelines for the
measurement and the
assessment of human
exposure to **hand-transmitted**
vibration.”

Evaluation Method: Rating



Evaluation Method: Weighting

Motion sickness


Acceleration
dB

Whole body

x,y


z

Hand-arm




Using the Weighing Method in Practice


Measurement



Weighting




Display




Measurement Directions

Whole-Body



"Handgrip" position



----- Basicentric coordinate system

—— Biodynamic coordinate system

Categories of Whole-Body Vibration

Motion sickness, in ships or vehicles with very soft suspension systems

– 0.1 to 0.63Hz




Whole-body vibration in vehicles or on platforms

– 1 to 80Hz




Whole-body vibration in buildings


– 1 to 80Hz




Whole-Body Vibration Weighting




Measure in the Vertical Direction In Buildings




Hand-Arm Vibration Weighting





Vibration Amplitude




Descriptive Parameters




Characteristics of Vibration – RMS




The “Energy Equivalent” Acceleration, a_{eq}




Max. Peak and Crest Factor




m/s² or Decibels?




m/s² or Decibels?




Basic Instrumentation for Weighted Measurements




Transducer for Whole-body Vibration




Mounting the Transducer – Whole Body



Whole-body Vibration in Buildings




Directional Considerations




Weighted Acceleration Sum:

$$WAS = \sqrt{(1.4a_x)^2 + (1.4a_y)^2 + a_z^2}$$

Exposure Evaluation



Calculation of the Working Day Dose



$$\text{Dose} = \left(\frac{t_1}{\tau_1} + \frac{t_2}{\tau_2} + \frac{t_3}{\tau_3} \right) \times 100\%$$

t = Elapsed time


τ = Allowed time

Example of Dose Calculation:

Work Type	Elapsed Time t (hours)	a_{eq} m/s^2	Allowed Time τ (hours)
1	2	0.7	2.5
2	0.5	1.3	0.9
3	1	0.3	8

$$\text{Dose} = \left(\frac{2}{2.5} + \frac{0.5}{0.9} + \frac{1}{8} \right) \times 100\% = 148\%$$


Approximated Exposure Evaluation



$$t_{allowed} = \left(\frac{a_0}{a_{eq}} \right)^2 \times t_0 \quad (1)$$

$$\text{Dose} = \frac{t_{elapsed}}{t_{allowed}} \times 100\% \quad (2)$$


Mounting the Transducer – Hand Arm




Accelerometers should be rigidly attached to the tool, but not interfering with normal operation

Mounting Adaptors – Hand Arm

Hand-adaptor




Handle adaptor




Handle adaptors and hand-adaptors are used when rigid mounting to the tool is not possible

Coordinate Systems




The hand adaptor measures in the biodynamic coordinate system




The handle adaptor measures in the basicentric coordinate system

Directional Considerations for Hand-Arm




For hand-arm vibration it is often necessary to measure in all three directions to find the worst one

Type of Adaptor





Handle adaptor

Hand-adaptor




Accelerometers Cables



Cables are fixed down, often with tape, so that there is minimal cable-induced vibration in the measurement system

Exposure Evaluation

Risk of getting vascular disorders (White finger syndrome)



The 4-hour Energy Equivalent Acceleration, $a_{eq}(4)$

m/s²

$$a_{eq}(4) = a_{eq}(t) \sqrt{\frac{T}{4}}$$

dB

$$L_{eq}(4) = L_{eq(T)} + 10 \log \frac{T}{4}$$

Exposure from Several Events

m/s²

$$a_{eq}(T) = \sqrt{\frac{a_1^2 T_1 + a_2^2 T_2 + a_3^2 T_3 + \dots}{T_1 + T_2 + T_3 + \dots}}$$

dB

$$L_{eq}(T) = 10 \log \frac{T_1 \text{ inv.log } \frac{L_1}{10} + T_2 \text{ inv.log } \frac{L_2}{10} + \dots}{T_1 + T_2 + \dots}$$

Example of Exposure Calculations

Work Type	a_n m/s ²	Effective time Hours
1	5.6	0.7
2	10.3	0.5
3	2.5	1.0



} = 2.2

$$a_{eq}(T) = \sqrt{\frac{5.6^2 \times 0.7 + 10.3^2 \times 0.5 + 2.5^2 \times 1.0}{0.7 + 0.5 + 1.0}} = 6.1 \text{ m/s}^2$$

$$a_{eq}(4) = 6.1 \times \sqrt{\frac{2.2}{4}} = 4.5 \text{ m/s}^2$$



$$a_{eq}(8) = 6.1 \times \sqrt{\frac{2.2}{8}} = 3.2 \text{ m/s}^2$$

Frequency Analysis – 1/3 Octave




Note: Different signals to the analyzers

Frequency Analysis – FFT





Note: Different signals to the analyzers


Level Analysis



Statistical Analysis




Example: Wheel-loader




Example: Wheel-loader

1/3 Octave Spectrum




Example: Helicopter

FFT Spectrum




Example: Chipping Hammer




Very high peak acceleration levels are found at the handle of the chipping hammer. Even higher levels are found at the chisel (and the operator often uses his other hand to control the chisel)


Chipping Hammer Vibration




Chipping Hammer Risk Evaluation





Example: Chain Saw



Chain Saw



Example: Grinders



**Weighted
1/3-octave
Spectrum**

Conclusion

Central Issue:

Avoid breaking occupational health legislation at lowest cost

Monitoring and Risk assessment checklist:

- Is there a problem?
- How big is the problem?
- What causes the problem?
- How do we reduce the problem?
- How do we prevent the problem?

Vibration + Time = Vibration Exposure

Vibration Exposure + Time = **Tissue Damage**

Vibration exposure is measured according to national and international standards for Hand-Arm Vibration and Whole-Body Vibration.